


GX-24 Menu Flowchart



→ - Press "ENTER" to confirm