What is "Firmware Installer"?

"Firmware Installer" is an application for installing firmware in user's printer.

Supported Environment

We recommend to use this application on operating system such as Microsoft® Windows 7, Vista, XP or 2000.

How to Install

It is not necessary to install Firmware Installer. Just put Firmware Installer Execution file on your computer.

Firmware Installer and Supported Model Series

<USB Connection>
• SP300Firm.exe： SP-300 Series

<Ethernet Connection>
• PRO2Firm.exe: ProII (V) Series
• AJFirm.exe: AJ-1000//740/1000i/740i
• FPFirm.exe: FP-740
• PRO3Firm.exe:
      XC-540, XJ-740/640/540
• VPFirm.exe: VP-540/300/540i/300i
• SJ1000Firm.exe: SJ-1000/1045EX
• SP540Firm.exe: SP-540V Series
• RSFirm.exe: RS-640/540
• LECFirm.exe: LEC-330/300/300A
• SPiFirm.exe: SP-540i/300i
• VSFirm.exe: VS-640

How to Uninstall

Delete the Firmware Installer Execution file from your computer. You don't need special way to uninstall.

How to Use

① Preparation for your printer
Turn on Main Power Switch and Turn off Sub Power Switch.
Please be confirmed that there is no printing data transmissions between the printer and your computer.

② Preparation for your computer
Please be confirmed that cable connections between printer and your computer.

③ Execution of Firmware Installer
Double-click Firmware Installer execution file and you can see the dialog as shown below and next page.

### <In case of USB connection>

If you click "Next" button, it proceeds next dialog.
If you click "Cancel" button, you can exit from Firmware Installer.

<In case of Ethernet connection>

If you set up the Roland VersaWorks, Model names are automatically listed in the box.

If there are not printer you want to install new firmware, choose "Manual Input" and fill in IP address in the box.


If you click "Next" button, it proceeds next dialog.
If you click "Cancel" button, you can exit from Firmware Installer.

④Checking Firmware Version and supported Models plus Start Installation.

<USB Connection>

<Ethernet Connection>

Please check model name and version before clicking "Install" button.
If you clicked "Back" button, the dialog goes back to the previous dialog.
If you click "Cancel" button, you can exit from Firmware Installer.

## ⑤during Installation

Don't change power switches during installation. It may takes a few minutes by your environment.

⑥End of installation

If the installation is successful, the message below will comes up and goes back to the top dialog.

About Message

Please check the version of Firmware Installer and version of your printer.

Roland Firmware Installer ✕

ⓘ Current version is 2.10.
Installation is not necessary.

OK

If the application cannot get information from Printer, please check the filled IP address, Main power switch ON, or connection of USB cable.
* In some series, this message comes out if the Supported model is different.

Roland Firmware Installer ✕

⚠ Cannot find a printer.
Fill in IP address again or turn on main power switch.

OK

Supported Model is different from Model type Firmware Installer Please Check the supported Models of Firmware Installer.

Roland Firmware Installer ✕

⚠ This Installer doesn't support XC-540.
Download Firmware Installer for it.

OK

If the Sub Power Switch is ON, the Message comes up.
Please turn off Sub Power Switch and click "OK" button.

Roland Firmware Installer ✕

⚠ Turn off SUB power switch.

OK

During Firmware Installer is executing, another Firmware Installer cannot execute. Please wait until the Firmware Installer finishes.

Roland Firmware Installer ✕

❌ Execution Error.
The previous Firmware Installer is still executing.

OK

If it failed to send Firmware, please restart your printer.
The message comes out If you change power switch during sending Firmware and if installed version is not valid version.

Roland Firmware Installer ✕

❌ Failed to send firmware.
Turn off main power switch and turn it on, then try installation again.

OK

Roland Firmware Installer ✕

❌ Failed to install firmware.
Turn off main power switch and turn it on, then try installation again.

OK

Cautions

In case of turning main power switch during installation, LCD shows "SUM ERROR". Then please contact your service engineer.

In case of installation by USB cable, Windows starts "new device" wizard after installation of firmware.
Please delete previous SP-300 series driver and install new one.