

Instruction for adding EGX-20 driver to EZ-Engrave

1. Unzip the “*EGX 20 EZ Engrave Update*” file to the *EZ-Engrave folder* located on your computers hard drive.
2. There are two files placed in your EZ-Engrave folder
3. Double-click the **AddADriver.exe** program located already in the EZ-Engrave folder
4. Click on File / Add then "Browse" to select the **egx-20.ini file**
5. Click "Add"
6. To close out of the AddADriver.exe, click on the X in the upper right corner.
7. When you go to Cut / Plotter Setup, the EGX 20 driver should be available.