

# PASSPORT



## Firmware Revision Record

9/21/2006

<b>Model:</b> XC-540	<b>Version:</b>	
	<b>Current</b> <b>1.10</b>	<b>New</b> <b>1.20</b>

### Following Problems have been Corrected

1. The amount of remaining ink displayed on the machine and RIP differs greatly from the actual amount.
2. If you enable [PERIODIC CL.] function in the user's menu, cleaning interval becomes shorter than its setting.
3. In [PRINT-CUT ADJ.]>[TEST PRINT] in the user's menu or the service menu, left edge of the pattern might not be cut.
4. If you set the temperature setting of any one of media heating system to [OFF] and then save the [PRESET] in the user's menu, the item that is set to [OFF] becomes [-100] in the system report.
5. In [TEST PATTERN]>[BI DIR.] in the service menu, test pattern is not printed out correctly.



# PASSPORT



## Firmware Revision Record

9/21/2006

<b>Model:</b> XC-540	<b>Version:</b> Current <b>1.00</b>	New <b>1.10</b>
-------------------------	---	--------------------

### Change in Spec

1. The range of the Test Pattern for Bidirectional Adjustment in Service Menu has been changed.

### Following Problems have been Corrected

1. Unwanted data lines might be printed in network environments with slow transmission speeds.
2. Sometimes the Crop Marks cannot be detected.
3. The cutting pauses for 3 seconds.
4. The value for [Crop-cut adjust(F/S)] set by Service Mode cannot be printed in Service Report.
5. A part of content in the Cleaning Menu is displayed differently from the manual.



# PASSPORT



## Firmware Revision Record

9/21/2006

**Model:**  
XC-540

**Version:**  
Current

New  
**1.00**

**Initial release**

